

TG-AS2J24007

# TYGER ACCESS

Scan to Download the Latest Digital Version



#### **BEFORE INSTALLATION**

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT: WWW.TYGERAUTO.COM/CONTACT

#### **TORQUE VALUES**

Class 8.8 Torque (ft-lbs)	Class 10.9 Torque (ft-lbs)
6-7	6-7
15-16	22-23
31-32	44-45
54-55	78-79
87-88	125-126
	15-16 31-32 54-55



#### **Top View**

ATTENTION: Refer to D and P labelling on the side of the tubes to determine Driver and Passenger TYGER Access



# 💱 TYGER<sup>®</sup>

## Reference the letters printed on the brackets to determine mounting locations







**Bottom View** 





## **TOOLS REQUIRED**







## **MOUNTING BRACKETS**

Follow (Fig 1 - 15) to attach the brackets to the Driver Side. Ensure hardware is hand tightened at this point.















# 😵 TYGER<sup>®</sup>





### STEP2 MOUNTING RUNNING BOARD

Follow (Fig 16-17) to install the Access Drop Step on the Driver/Left Side. Ensure all hardware is hand tightened at this point.





# **TYGER**



Repeat **STEPS 1-2** for passenger side installation. Use <u>Front</u> Mounting Bracket **[D]** instead of **[A]**; Use <u>Center</u> Mounting Bracket **[E]** instead of **[B]**; Use <u>Rear</u> Mounting Bracket **[F]** instead of **[C]**; Use <u>Front</u> Support Bracket **[I]** instead of **[G]**; Use <u>Center & Rear</u> Support Brackets **[J]** instead of **[H]**.





# COMPLETION

Ensure Tyger Access Drop Step is level and straightened, then tighten all fasteners. Installation is complete. Perform periodic inspections to the installation to make sure that all hardware is secure and tight.

