

# TYGER BLADE

### TG-BL7T7238

#### **BEFORE INSTALLATION TORQUE VALUES** READ INSTRUCTIONS CAREFULLY BEFORE STARTING **Fastener Size** Class 8.8 Torque (ft-lbs) Class 10.9 Torque (ft-lbs) INSTALLATION. REMOVE CONTENTS FROM BOX AND 6mm 6-7 6-7 VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY 8mm 15-16 22-23 DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY 31-32 44-45 10mm DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE 12mm 54-55 78-79 CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT: WWW.TYGERAUTO.COM/CONTACT 14mm 87-88 125-126 x8 8mm Double Bolt Plates x16 8mm Nylon Lock Nuts x2 78" Running Boards x2 Front Mounting Brackets [A] x16 8-1.25mm x 30mm Hex Bolts x2 Center Mounting Brackets [B] x16 8mm Lock Washers Rear Mounting Brackets [C] 8mm x 24mm x 2mm Flat Washers Parts List **Top View Passenger Side Blade** Front 1/3/1/1/1 Front **Driver Side Blade** [A] **[B]** [C] Front Mounting Brackets Center Mounting Brackets **Rear Mounting Brackets** 8mm Double Bolt Plates 8-1.25mm x 30mm Hex Bolts 8mm Nylon Lock Nuts 8mm Lock Washers 8mm x 24mm x 2mm Flat Washers









Passenger Side Blade

# **TYGER**<sup>®</sup>









## Driver-side <u>2<sup>nd</sup> Center</u> Mounting Area







Driver-side <u>Rear</u> Mounting Area











Follow (Fig 13 - 14) to install the running board.







# **PASSENGER SIDE**

Repeat STEPS 1-2 for passenger side installation. <u>Make sure</u> that all hardware is secure and tight after preferred adjustments.





Installation is complete. Do periodic inspections to the installation to make sure that all hardware is secure and tight.