



TYGER®

TYGER GUARD™

TG-GD6G60548

BEFORE INSTALLATION


READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT: WWW.TYGERAUTO.COM/CONTACT

TORQUE VALUES

Fastener Size	Class 8.8 Torque (ft-lbs)	Class 10.9 Torque (ft-lbs)
6mm	6-7	6-7
8mm	15-16	22-23
10mm	31-32	44-45
12mm	54-55	78-79
14mm	87-88	125-126

Parts List

- x1 Tyger Guard
- x1 Driver/Left Frame Bracket
- x1 Passenger/Right Frame Bracket
- x1 Driver/Left Mounting Bracket
- x1 Passenger/Right Mounting Bracket
- x6 10-1.5mm x 35mm Bolt Plates
- x2 10-1.5mm x 35mm Double Bolt Plates
- x10 10mm x 30mm OD x 2.5mm Flat Washers
- x10 10mm Lock Washers
- x10 10mm Hex Nuts
- x6 10mm Plastic Retainers
- x4 8-1.25mm x 35mm Hex Bolts
- x4 8mm Lock Washers
- x4 8mm x 22mm OD x 2mm Flat Washers
- x2 6-1.0mm x 20mm Button Head Combo Bolts
- x1 4mm Hex Wrench





TYGER[®]


PROCEDURE:

REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY. CUTTING MAY BE REQUIRED. INSTALLATION MAY INTERFERE WITH FRONT MOUNTED SENSORS.


STEP 1

1. Remove the factory tow hook and plastic cover, if equipped (Figs 1 & 2).

Driver/Left Side Installation Pictured



(Fig 1) Driver/Left tow hook pictured




(Fig 2) Remove the tow hook and the plastic cover

STEP 2

For models not equipped with tow hooks, cut out the indented area in both sides of the plastic bumper insert to clear the Brackets as pictured (Fig 3).

IMPORTANT: Make several small cuts for best fit. DO NOT cut through the top or bottom edge of the panel.

Driver/Left Side Installation Pictured



(Fig 3) Example of model without tow hooks, driver/left side pictured

STEP 3

Select the Driver/Left Frame Bracket. Line up the holes in the Frame Bracket with the holes in the outer frame for the tow hook.


Models without tow hooks:

- a. Select (3) 10mm Bolt Plates. Insert the Bolt Plates into the end of the frame (Fig 4). Thread (1) 10mm Plastic Retainer onto each of the (3) Bolt Plates to hold it in place (Fig 5)..




TYGER®

Driver/Left Side Installation Pictured




(Fig 4) Driver/Left side of frame and bumper pictured from behind bumper




(Fig 5) Attach (1) 10mm Bolt Plate to the inside of the frame

b. Attach the Frame Bracket to the Bolt Plates with (3) 10mm Flat Washers, (3) 10mm Lock Washers and (3) 10mm Hex Nuts (Figs 6 & 7). DO NOT tighten hardware at this time.



(Fig 6) Attach Driver/Left Frame Bracket to end of frame with Bolt Plate




(Fig 7) Driver/Left Frame Bracket attached to the end of the frame



TYGER®

c. Select (1) 10mm Double Bolt Plate (Fig 8). Insert the Double Bolt Plate into the outer side of the frame.

- (1) 10mm Double Bolt Plate
- (2) 10mm Flat Washers
- (2) 10mm Lock Washers
- (2) 10mm Hex Nuts



(Fig 8) Attach Driver/Left Mounting Bracket to the inner face of the Frame Bracket

d. Select the Drive/Left Mounting Bracket. Attach the Mounting Bracket to the Double Nut Plate with (2) 10mm Flat Washers, (2) 10mm Lock Washers and (2) 10mm Hex Nuts (Fig 8). DO NOT tighten hardware at this time

Models with tow hooks:

a. Attach the mounting tab on the Frame Bracket to the Frame with (1) 10mm Bolt Plate, (1) 10mm Plastic Retainer, (1) 10mm Flat Washer, (1) 10mm Lock Washer and (1) 10mm Hex Nut. DO NOT tighten hardware at this time.


b. Reuse the factory hardware to attach the upper holes in the Driver/Left Frame Bracket to the end of the frame.

STEP 4

Repeat **STEPS 2 & 3** to attach the Passenger/Right Frame and Mounting Brackets.

STEP 5

With assistance, hold the Tyger Guard up in position to the Mounting Brackets. Attach the Tyger Guard to the Mounting Brackets with (4) 18mm Hex Bolts, (4) 12mm Lock Washers and (4) 8mm Flat Washers (Fig 9). DO NOT tighten hardware at this time.



(Fig 9) Attach the Tyger Guard to the Driver/Left Mounting Bracket

STEP 6

Level and adjust the Tyger Guard and fully tighten all hardware.

STEP 7

Do periodic inspections to the installation to make sure that all hardware is secure and tight.