

HITCH KIT

TG-HC3D002B

BEFORE INSTALLATION

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT: WWW.TYGERAUTO.COM/CONTACT


TORQUE VALUES

Fastener Size	Class 8.8 Torque (ft-lbs)	Class 10.9 Torque (ft-lbs)
6mm	6-7	6-7
8mm	15-16	22-23
10mm	31-32	44-45
12mm	54-55	78-79
14mm	87-88	125-126

Parts List

For: 2003-2018 RAM 1500 2003-2013 RAM 2500/3500

- Receiver Towing Hitch
- M14 Bolt Plate
- M14 Hex Nut
- M14 Flat Washer
- x2 M14 Fishwire
- x2 M14 Lock Washer
- x1 Flat Head Socket Cap Screw, ZP




PROCEDURE:


REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.



Remove existing trailer ball hole cap on center of bumper and set aside (Fig 1).




Insert coiled end of the fishwire tool through hitch mounting hole in vehicle frame tube (Fig 3).




STEP 2

Raise the hitch into position and secure with flat head socket cap screw through the bumper and bumper support into the hitch (Fig 2).




Pull coiled end of the fishwire out of the frame tube hole (Fig 4).



Customer Support: www.tygerauto.com/contact


STEP 5

Attach bolt plate onto fishwire then insert into frame tube (Fig 5).




STEP 6

Pull bolt plate out in hitch mounting hole through frame tube. (Then repeat **STEP 3-6** for the other bolt plate.)




STEP 7

Secure the two bolt plates with washers and nuts. Torque hardware to 100 lb -ft (Fig 7).



STEP 8

Torque the flat head socket cap screw to 250 lb-ft. Installation complete (Fig 8).



Customer Support: www.tygerauto.com/contact