



TYGER[®]

SPORT BAR

TG-SB7D88348

BEFORE INSTALLATION

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT: WWW.TYGERAUTO.COM/CONTACT

DISCLAIMER


THIS PRODUCT IS NOT DESIGNED TO WORK AS A SAFETY DEVICE AGAINST ROLLOVER ACCIDENTS. TYGER AUTO IS NOT RESPONSIBLE OR LIABLE FOR ANY DAMAGES & INJURIES AS A RESULT OF A ROLLOVER ACCIDENTS.

TORQUE VALUES

| Fastener Size | Class 8.8 Torque (ft-lbs) | Class 10.9 Torque (ft-lbs) |
|---------------|---------------------------|----------------------------|
| 6mm | 6-7 | 6-7 |
| 8mm | 15-16 | 22-23 |
| 10mm | 31-32 | 44-45 |
| 12mm | 54-55 | 78-79 |
| 14mm | 87-88 | 125-126 |

Parts List

- | | | |
|---|--|--|
| <ul style="list-style-type: none">x1 Front Cross Tubex1 Driver/Left Support Tubex1 Passenger/Right Support Tubex1 Driver/Left Decorative Platex1 Passenger/Right Decorative Platex1 Driver/Left Logo Platex1 Passenger/Right Logo Platex2 Rubber Plugsx2 LED Light Bar Brackets | <ul style="list-style-type: none">x1 Driver/Left Base Bracketx1 Passenger/Right Base Bracketx1 Driver/Left Plastic Sleevex1 Passenger/Right Plastic Sleevex4 Plastic Base Coversx4 12-1.75mm x 35mm Flat Head Screwsx2 12-1.5mm x 60mm Button Head Boltsx2 12mm Lock Washersx2 12mm x 24mm x 2.5mm Flat Washersx2 8-1.25mm x 16mm Hex Boltsx2 8-1.25mm x 25mm Hex Boltsx6 8-1.25mm x 40mm Hex Bolts | <ul style="list-style-type: none">x6 8mm Nut Platesx12 8mm x 24mm x 2mm Flat Washersx10 8mm Lock Washersx2 8mm Hex Nutsx8 6mm Flange Nutsx2 6mm Button Head Combo Boltsx1 12mm Fish Wirex1 8mm Hex Wrenchx1 4mm Hex Wrench |
|---|--|--|









TYGER®

PROCEDURE:

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. ASSISTANCE IS RECOMMENDED. DRILLING IS REQUIRED. CUTTING OF PLASTIC BED LINER (IF EQUIPPED) MAY BE REQUIRED.

STEP 1

Select Front Cross Tube. Insert (1) 12mm Button Head Bolt into (1) 12mm Lock Washer and (1) 12mm Flat Washer. Thread the bolt assembly into the 12mm Fish Wire, (Figure 1). Slide the Fish Wire assembly through the holes in the Front Cross Tube, (Figures 2 & 3). Insert 8mm Hex Wrench into the head of the bolt to hold it in place inside the tube, (Figure 4).




STEP 2

Slide the Passenger/ Right Plastic Sleeve onto the Passenger/Right Rear Support Tube. Thread 12mm Button Head Bolt into the Passenger/Right Support Tube, (Figures 4 & 5).



TYGER®




(Fig 5) Passenger/Right Support Tube installed

STEP 3

Repeat Steps 1 & 2 to attach the Driver/Left Rear Support Tube. DO NOT tighten hardware at this time.

STEP 4

Insert (2) Plastic Base Cover onto the bottom of the tubes. Select the Passenger/Right Base Bracket. Attach the Base Bracket to the bottom of the tubes with (2) 12mm Flat Head Bolts, (Figure 6). DO NOT tighten hardware at this time. Repeat this STEP to install the Driver/Left Base Bracket.




(2) 12mm Flat Head Bolts


(Fig 6) Passenger/Right Base Bracket installation

STEP 5

Select the Passenger/Right Decorative Plate. Attach the Plate to the welded brackets on the sides of the tubes with (4) Flanged Nuts, (Figures 7 & 8). Repeat STEP to install the Driver/Left Decorative Plate.



(Fig 7) Passenger/Right Decorative Plate installation



(Fig 8) Passenger/Right Decorative Front installed



TYGER®


STEP 6

With assistance, place the Sports Bar assembly onto the desired position on the bed of the vehicle. The Front Cross Tube should be at least 30mm away from the rear of the cab. Mark the holes in the Base Brackets to determine locations to drill holes in the lip of the bed, (Figures 9 & 10). Temporarily remove the Sports Bar. Using a 5/16" drill bit, drill holes for mounting, (Figures 11 & 12).


IMPORTANT: DO NOT drill too closely to the edge of the bed. Repeat this Step for the Driver/Left side. To Prevent rust, apply a thin layer of paint over the exposed metal.




(Fig 9) Front Cross Tube must be at least 30mm from the rear of the cab



(Fig 10) Mark where the holes are on the top of the bed walls



(Fig 11) Drill marked locations with a 5/16" drill bit



(Fig 12)


STEP 7

Attach Sports Bar assembly to the bed with (3) 8mm x 40mm Hex Bolts, (3) 8mm Lock Nuts, (3) 8mm Flat Washers and (3) 8mm Nut Plates (Behind the top of the bed), (Figures 13 & 14). Tighten all hardware at this time.




TYGER[®]

- (3) 8mm x 40mm Hex Bolts
- (3) 8mm Lock Washers
- (3) 8mm Flat Washers
- (3) 8mm Nut Plates



(Fig 13) Passenger/Right Base Bracket to bed installation




(Fig 15) Insert Rubber Plug into Hole

STEP 9

Select (1) LED Light Bracket. Attach to the top of the Sports Bar with (1) 8mm x 25mm Hex Bolt, (2) 8mm Flat Washers, (1) 8mm Lock Washer and (1) 8mm Hex Nut, (Figure 16).

- 8mm x 25mm Hex Bolt
- (2) 8mm Flat Washers
- 8mm Lock Washer
- 8mm Hex Nut



(Fig 16) LED Light Bracket installation

STEP 8

Select (2) Rubber Plugs. Insert Plugs into the front holes of the Front Cross Tube, (Figure 15).




TYGER®

STEP 10

Attach LED Light Bar (sold separately) to the LED Light Bracket with (1) 8mm x 16mm Hex Bolt, (1) 8mm Lock Washer and (1) 8mm Flat Washer, (Figure 17).


8mm x 16mm Hex Bolt
8mm Lock Washer
8mm Flat Washer




(Fig 17) LED installation

STEP 11


(OPTIONAL, if a Tonneau cover is installed, skip this step) Locate the threaded mounting hole on the inside of the Base Brackets for the Passenger/Right Logo Plate. Attach Plate with one 6mm Combo Bolt, (Figures 18—20).



(Fig 18) Passenger/Right Logo Plate



(Fig 19) Passenger/Right Logo Plate installation (Optional)



(Fig 20) Logo Plate installed

STEP 12

Do periodic inspections to the installation to make sure that all hardware is secure and tight.