



TYGER®

STAR ARMOR®

TG-AM2F20708

BEFORE INSTALLATION


READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT: WWW.TYGERAUTO.COM/CONTACT

TORQUE VALUES

| Fastener Size | Class 8.8 Torque (ft-lbs) | Class 10.9 Torque (ft-lbs) |
|---------------|---------------------------|----------------------------|
| 6mm | 6-7 | 6-7 |
| 8mm | 15-16 | 22-23 |
| 10mm | 31-32 | 44-45 |
| 12mm | 54-55 | 78-79 |
| 14mm | 87-88 | 125-126 |

Parts List

- x1 Driver/Left TYGER Armor
- x1 Passenger/Right TYGER Armor
- x12 10mm x 30mm Hex Bolts
- x12 10mm Lock Washers
- x12 10mm X 27mm OD x 3mm Flat Washers





TYGER®


STEP 1

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.

STEP 2

Starting from underneath the passenger/right body panel, locate the front mounting location and the threaded holes in the body panel (Fig 1). Remove the plastic plugs covering the holes.

Passenger/Right Side Installation Pictured




(Fig 1) Passenger/right front mounting location

STEP 3

Select the Passenger/Right TYGER Armor. Attach the TYGER Armor to the front location with (2) 10mm Hex Bolts, (2) 10mm Lock Washers and (2) 10mm Flat Washers (Fig 2). DO NOT tighten hardware.

Passenger/Right Side Installation Pictured

- (2) 10mm Hex Bolts
- (2) 10mm Lock Washers
- (2) 10mm Flat Washers




(Fig 2) Attach the Passenger/Right TYGER Armor to the front mounting location

STEP 4

Repeat **STEPS 2 & 4** to attach the TYGER Armor to the center and rear locations (Figs 3-5). DO NOT tighten hardware.

Passenger/Right Side Installation Pictured




(Fig 3) Passenger/right center mounting location




TYGER®

(2) 10mm Hex Bolts
(2) 10mm Lock Washers
(2) 10mm Flat Washers



(Fig 4) Attach Passenger/Right TYGER Armor to the center and rear locations



(Fig 5) Passenger/right rear mounting location

STEP 7

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

STEP 5

Level and adjust the Tyger Armor and tighten all hardware.

STEP 6

Repeat **STEPS 1-5** to attach the Driver/Left TYGER Armor.