



# TYGER®

## TYGER ACCESS

TG-AS2C24011

Scan to Download the  
Latest Digital Version



### BEFORE INSTALLATION

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT:

[WWW.TYGERAUTO.COM/CONTACT](http://WWW.TYGERAUTO.COM/CONTACT)

### TORQUE VALUES



Fastener Size	Class 8.8 Torque (ft-lbs)	Class 10.9 Torque (ft-lbs)
6mm	6-7	6-7
8mm	15-16	22-23
10mm	31-32	44-45
12mm	54-55	78-79
14mm	87-88	125-126

- |  |                                      |                                     |
|--|--------------------------------------|-------------------------------------|
| x1 Driver/Left Tyger Access                          | x1 8mm x 28mm OD x 3mm Flat Washer   | x16 8-1.25mm x 25mm Hex Combo Bolts |
| x1 Passenger/Right Tyger Access                      | x17 8mm Lock Washers                 |                                     |
| x4 Driver/Left Mounting Brackets [A]                 | x15 8mm Clip Nuts                    |                                     |
| x1 Passenger/Right Front Mounting Bracket [B]        | x17 8mm x 24mm OD x 2mm Flat Washers |                                     |
| x3 Passenger/Right Center/Rear Mounting Brackets [C] | x1 8-1.25mm x 40mm Hex Bolt          |                                     |
| x1 Passenger/Right Front Support Bracket [D]         | x16 8-1.25mm x 25mm Hex Bolts        |                                     |
| x1 T-Shape Bolt Plate                                | x1 8mm Nylon Lock Nut                |                                     |

### Parts List

### Top View



**ATTENTION:** Refer to **D** and **P** labelling on the side of the tubes to determine Driver and Passenger TYGER Access



Reference the letters printed on the brackets to determine mounting locations

## Top View



**D** Driver Side TYGER Access



**P** Passenger Side TYGER Access



## Bottom View

**D** Driver Side TYGER Access





**P** Passenger Side TYGER Access

## TOOLS REQUIRED





## STEP 1 MOUNTING BRACKETS

Follow (Fig 1 – 7) to attach the brackets to the Driver/Left Side. **Ensure all hardware is hand tightened for this step.**





**Driver-side Front Mounting Areas**






### Driver-side Center and Center-Rear Mounting Areas




### Driver-side Rear Mounting Area



## STEP 2 MOUNTING RUNNING BOARD

Follow (Fig 8) to install the Access Side Step on the Driver/Left. Ensure all hardware is **hand tightened** at this point.




## STEP 3 PASSENGER SIDE

Repeat **STEP 1** to install mounting brackets to the 3 mounting locations at Passenger/Right Center, Center-Rear, and Rear.

Use Mounting Brackets [C] instead of [A].



Continue to **STEP 4** for the Passenger/Right Front mounting location instruction.




## STEP 4 PASSENGER SIDE FRONT MOUNTING BRACKET

Follow (Fig 9 – 19) to remove DEF tank cover and install the Passenger/Right Front Mounting and Support Brackets. Ensure all hardware is **hand tightened** at this point.






(Fig 9) **07-16** Passenger/Right Front pictured with DEF tank cover. Remove (3) hex bolts to remove cover



Remove (2) factory bolts to remove tank straps


(Fig 10) **07-16** Passenger side DEF tank and cover



(Fig 11A) **2017-on** Passenger/right side pictured with DEF plastic tank cover. Remove (4) hex bolts to remove plastic cover




(Fig 11B) **2017** Passenger side DEF cover removed




(Fig 12) Passenger/right side front mounting location with weld nut pictured for example

- (1) 8-1.25 x 25mm Hex Bolt
- (1) 8mm Lock Washer
- (1) 8mm x 24mm x 2mm Flat Washer




(Fig 13) Attach Passenger/Right Front Support Bracket (D)

For models **with weld nut**




(Fig 14) Slide Passenger/Right Support Bracket (D) over weld nut if equipped

- (1) 8-1.25 x 40mm Hex Bolt
- (1) 8mm Lock Washer
- (1) 8mm x 28mm x 3mm Flat Washer




(Fig 15) For models with weld nut, attach Passenger/Right Front Mounting Bracket (B) directly to weld nut

For models **with flat tab**




(Fig 16) On models with flat tab (Fig 3 & 4) insert 8mm Bolt Plate (Fig 15) down through Support Bracket (D) and mounting tab

- (1) 8mm T-Bolt
- (1) 8mm x 24mm x 2mm Flat Washer
- (1) 8mm Lock Nut




(Fig 17) Attach Passenger/Right Front Mounting Bracket (B)

- (1) 8-1.25mm x 25mm Hex Bolt
- (1) 8mm Lock Washer
- (1) 8mm x 24mm x 2mm Flat Washer



(Fig 18) Attach Passenger/Right Front Support Bracket (D) and Passenger/Right Front Mounting Bracket (B)



(Fig 19) Attached Passenger/Right Front Support Bracket (D) and Mounting Bracket (B)

## STEP 5

Ensure Access Drop Step is level and straightened, then **tighten all fasteners**. Installation is complete. Perform periodic inspections to the installation to make sure that all hardware is secure and tight.



Complete Installation