



TYGER®

BLADE®

TG-BL8F7188


BEFORE INSTALLATION

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT: WWW.TYGERAUTO.COM/CONTACT

Fastener Size	Class 8.8 Torque (ft-lbs)	Class 10.9 Torque (ft-lbs)
6mm	6-7	6-7
8mm	15-16	22-23
10mm	31-32	44-45
12mm	54-55	78-79
14mm	87-88	125-126

PARTS LIST

- | | | |
|--|--|-------------------------------------|
| x2 Running Boards | x10 8mm x 28mm x 3mm Large Flat Washers | x10 8mm Clip Nut |
| x4 Mounting Brackets | x20 8mm Lock Washers | x20 8-1.25mm x 30mm Hex Bolt |
| x1 Driver/Left Center Bracket | x32 8mm x 24mm x 2mm Flat Washers | x20 8-1.25mm x 25mm Hex Bolt |
| x1 Passenger/Right Center Bracket | x10 8mm Hex Nuts | |
| x6 Double Flat Brackets | x12 8mm Nylon Lock Nut | |





PROCEDURE

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.

STEP 1




Starting on the driver side of the vehicle, locate the (2) holes in the bottom of the body panel, (pinch weld), toward the front tire, (Figure 1). Next locate the rectangular opening and (2) small holes in the inner body panel directly above the holes in the pinch weld, (Figures 1 & 2). NOTE: The holes in the inner panel may be covered with sealing tape or insulation.

STEP 2

Slide (1) 8mm Clip Nut into the rectangular opening with the nut towards the inside. Line up the threaded nut on the clip with the round hole, (Figure 2). Repeat to install the 2nd 8mm Clip Nut in remaining hole location.

STEP 3

Select the Driver/left side Front Bracket, (Figure 3). Attach the Bracket to the (2) Clip Nuts with the included (2) 8mm x 28mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm x 28mm Large Flat Washers, (Figures 3). Depending on model and year, the brake cable may be run on the inside of the Bracket. Do not tighten hardware at this time.






STEP 4

Align the bottom holes in the front Bracket with the (2) holes in the pinch weld. Bolt the Bracket to the pinch weld using the included (2) 8mm x 24mm Hex Bolts, (4) 8mm Flat Washers, (2) 8mm Lock Washers and (2) 8mm Hex Nuts, (Figures 4).


(2) 8mm x 24mm Hex Bolts
(2) 8mm Lock Washers
(4) 8mm x 24mm Flat Washers
(2) 8mm Clip Nuts



STEP 5

Next, move toward the center of the vehicle. Locate the (2) holes in the pinch weld similar to the front location, Insert (1) 8mm Clip Nut into the rectangular opening and up to the single small round hole in the body panel, (Figure 5).


8mm Clip Nut



STEP 6

Select the Driver/left side Center Mounting Bracket. (Figure 6). Attach the Bracket to the Clip Nut with (1) 8mm x 28mm Hex Bolt, (1) 8mm Lock Washer and (1) 8mm x 28mm Large Flat Washer, (Figure 6). Line up the hole in the Bracket with the hole in the pinch weld. Bolt the Bracket to the pinch weld with (1) 8mm x 24mm Hex Bolt, (2) 8mm x 24mm Flat Washers, (1) 8mm Lock Washer and (1) 8mm Hex Nut. Do not tighten hardware at this time.

8mm x 28mm Hex Bolts
8mm Lock Washers
8mm x 28mm Flat Washers
8mm Clip Nuts





STEP 7





Continue along the cab to the rear mounting location, (Figure 8). Locate the last (2) mounting holes in the pinch weld towards the back of the cab. Repeat Steps 2—4 to install the Driver/left side Rear Mounting Bracket, (Figure 9). NOTE: The cradle on the Rear Bracket should face the front of the vehicle.

STEP 8

Select (1) Running Board and (3) 8mm Double Bolt Plates. Place the Running Board on top of the (3) Brackets. Insert the Bolt Plates into the channel in the bottom of the Running Board closest to the Brackets, (Figure 8). Lift the Running Board up and guide the studs down through the Brackets.

STEP 9

Attach the Running Board to the Brackets with (6) 8mm x 24mm Flat Washers and (6) 8mm Nylon Lock Nuts, (Figure 9). Do not tighten hardware at this time.





STEP 10

Level and adjust the Sidebar and fully tighten all hardware.

STEP 11

Repeat Steps 2—10 for passenger Sidebar installation.

STEP 12

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

