



TYGER LanderX

TG-LX3J82518

BEFORE INSTALLATION

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT: WWW.TYGERAUTO.COM/CONTACT

TORQUE VALUES




Fastener Size	Class 8.8 Torque (ft-lbs)	Class 10.9 Torque (ft-lbs)
6mm	6-7	6-7
8mm	15-16	22-23
10mm	31-32	44-45
12mm	54-55	78-79
14mm	87-88	125-126

- x1 Driver Side TYGER LanderX **[D]**
- x1 Passenger Side TYGER LanderX **[P]**
- x1 Driver Side Front Bracket **[A]**
- x1 Driver Side Center Bracket **[B]**
- x1 Driver Side Rear Bracket **[C]**
- x1 Passenger Side Front Bracket **[D]**
- x1 Passenger Side Center Bracket **[E]**
- x1 Passenger Side Rear Bracket **[F]**
- x3 Driver Side Support Brackets **[G]**
- x3 Passenger Side Support Brackets **[H]**
- x6 10mm Nut Plates
- x12 6-1.0mm x 25mm Hex Bolts
- x6 8-1.25mm x 35mm Hex Bolts
- x6 10-1.5mm x 30mm Hex Bolts
- x6 10-1.5mm x 35mm Hex Bolts
- x12 8mm Combo Bolts
- x24 6mm x 22mm x 2mm Flat Washers
- x6 8mm x 28mm x 3mm Flat Washers
- x12 10mm x 20mm x 2mm Flat Washers
- x6 10mm x 34mm x 3mm Flat Washers
- x6 8mm Lock Washers
- x6 10mm Lock Washers
- x12 6mm Nylon Lock Nuts
- x6 10mm Nylon Lock Nuts

Parts List

Top View

ATTENTION: Refer to **[D]** and **[P]** labelling on the side of the tubes to determine Driver and Passenger LanderX



- x6 10mm Nut Plates


- x12 6-1.0mm x 25mm Hex Bolts
 - x6 8-1.25mm x 35mm Hex Bolts
 - x6 10-1.5mm x 30mm Hex Bolts
 - x6 10-1.5mm x 35mm Hex Bolts

- x24 6mm x 22mm x 2mm Flat Washers
 - x6 8mm x 28mm x 3mm Flat Washers
 - x12 10mm x 20mm x 2mm Flat Washers
 - x6 10mm x 34mm x 3mm Flat Washers


- x12 6mm Nylon Lock Nuts
 - x6 10mm Nylon Lock Nuts

- x6 8mm Lock Washers
 - x6 10mm Lock Washers

Reference the letters printed on the brackets to determine mounting locations




D Driver Side Star Strider




P Passenger Side Star Strider

Bottom View






D Driver Side Star Strider




P Passenger Side Star Strider

TOOLS REQUIRED




STEP 1 MOUNTING BRACKETS


Follow (Fig 1 – 13) to attach the brackets to the Passenger Side.



Passenger-side Front Mounting Area




(Fig 1) Attach Bracket [D] to the Passenger/Right Side front mounting location with threaded insert or hole. Attach Bracket [H] to the pinch weld mounting locations






(Fig 5) Attached Bracket [D] and Support Bracket [H]

Passenger-side Center Mounting Area




(Fig 6) Attach Bracket [E] to the Passenger/Right Side center mounting location with threaded insert or hole. Attach Bracket [H] to the pinch weld mounting locations.






(Fig 9) Attached Bracket [E] and Support Bracket [H]

Passenger-side Rear Mounting Area




(Fig 10) Attach Bracket [F] to the Passenger/Right Side rear mounting location with threaded insert or hole. Attach Bracket [H] to the pinch weld mounting locations.




STEP 2 MOUNTING RUNNING BOARDS

Follow (Figs 14) to install the passenger-side running board.



STEP 3 DRIVER SIDE

Repeat **STEPS 1-2** for driver side installation.
 Use Front Bracket **[A]** instead of **[D]**;
 Use Center Bracket **[B]** instead of **[E]**;
 Use Rear Bracket **[C]** instead of **[F]**;
 Use Support Bracket **[G]** instead of **[H]**;



STEP 4

Installation is complete. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

