



## TYGER LanderX

TG-LX3J82628

### BEFORE INSTALLATION

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT:

[WWW.TYGERAUTO.COM/CONTACT](http://WWW.TYGERAUTO.COM/CONTACT)

### TORQUE VALUES




Fastener Size	Class 8.8 Torque (ft-lbs)	Class 10.9 Torque (ft-lbs)
6mm	6-7	6-7
8mm	15-16	22-23
10mm	31-32	44-45
12mm	54-55	78-79
14mm	87-88	125-126

- |  |   |   |
|--|---|---|
| <b>x1</b> Driver/Left TYGER LanderX <b>[D]</b>               | <b>x1</b> Driver/Left Front Support Bracket <b>[G]</b>            | <b>x6</b> 10mm Nylon Lock Nuts              |
| <b>x1</b> Passenger/Right TYGER LanderX <b>[P]</b>           | <b>x2</b> Driver/Left Center/Rear Support Brackets <b>[H]</b>     | <b>x12</b> 6-1.0mm x 25mm Hex Bolts         |
| <b>x1</b> Driver/Left Front Mounting Bracket <b>[A]</b>      | <b>x1</b> Passenger/Right Front Support Bracket <b>[J]</b>        | <b>x6</b> 8-1.25mm x 35mm Hex Bolts         |
| <b>x1</b> Driver/Left Center Mounting Bracket <b>[B]</b>     | <b>x2</b> Passenger/Right Center/Rear Support Brackets <b>[K]</b> | <b>x6</b> 10-1.5mm x 30mm Hex Bolts         |
| <b>x1</b> Driver/Left Rear Mounting Bracket <b>[C]</b>       | <b>x6</b> 8mm Lock Washers  | <b>x12</b> 10mm x 24mm x 2.2mm Flat Washers |
| <b>x1</b> Passenger/Right Front Mounting Bracket <b>[D]</b>  | <b>x24</b> 6mm x 22mm x 2mm Flat Washers                          | <b>x12</b> 8-1.25mm x 25mm Combo Bolts      |
| <b>x1</b> Passenger/Right Center Mounting Bracket <b>[E]</b> | <b>x6</b> 8mm x 28mm x 3mm Flat Washers                           |   |
| <b>x1</b> Passenger/Right Rear Mounting Bracket <b>[F]</b>   | <b>x6</b> 6mm Nylon Lock Nuts                                     |   |

Parts List




### Top View

**ATTENTION:** Refer to **[D]** and **[P]** labelling on the side of the tubes to determine Driver and Passenger LanderX







- |  |   |
|--|---|
|  | <b>x12</b> 6-1.0mm x 25mm Hex Bolts         |
|  | <b>x6</b> 8-1.25mm x 35mm Hex Bolts         |
|  | <b>x6</b> 10-1.5mm x 30mm Hex Bolts         |
|  | <b>x6</b> 8mm Lock Washers                  |
|  | <b>x24</b> 6mm x 22mm x 2mm Flat Washers    |
|  | <b>x6</b> 8mm x 28mm x 3mm Flat Washers     |
|  | <b>x12</b> 10mm x 24mm x 2.2mm Flat Washers |
|  | <b>x12</b> 8-1.25mm x 25mm Combo Bolts      |
|  | <b>x12</b> 6mm Nylon Lock Nuts              |
|  | <b>x6</b> 10mm Nylon Lock Nuts              |

Reference the letters printed on the brackets to determine mounting locations




**D** Driver Side LanderX




**P** Passenger Side LanderX

**Bottom View**





**D** Driver Side LanderX




**P** Passenger Side LanderX


## TOOLS REQUIRED



(Fig 2) Attach Driver/Left Front Mounting Bracket **[A]** to threaded insert at driver side front mounting location




(Fig 3) Attach Driver/Left Front Support Bracket **[G]** to the pinch weld mounting slots with its lower tab on the front side of Driver/Left Front Mounting Bracket **[A]**




(Fig 4) Attach Driver/Left Front Support Bracket **[G]** to Driver/Left Front Mounting Bracket **[A]**

## STEP 1 MOUNTING BRACKETS


Follow (Fig 1 – 16) to attach the Mounting Brackets to the Driver Side.




### Driver-side Front Mounting Area



(Fig 1) Locate the threaded inserts and holes in the front pinch weld




(Fig 5) Attach Driver/Left Front Mounting Bracket [A] and Driver/Left Front Support Bracket [G]




(Fig 8) Attach Driver/Left Center Support Bracket [H] to the pinch weld mounting slots with its lower tab on the rear side of Driver/Left Center Mounting Bracket [B]


**Driver-side Center Mounting Area**




(Fig 6) Locate the threaded inserts and holes in the pinch weld for center mounting location



(Fig 9) Attach Driver/Left Center Support Bracket [H] to Driver/Left Center Mounting Bracket [B]




(Fig 7) Attach Driver/Left Center Mounting Bracket [B] to Center Mounting Location Insert




(Fig 10) Attach Driver/Left Center Support Bracket [H] and Driver/Left Center Mounting Bracket [B]


**Driver-side Rear Mounting Area**




(Fig 11) Locate the threaded inserts and holes in the pinch weld for rear mounting location




(Fig 12) Attach Driver/Left Rear Mounting Bracket [C] to Rear Mounting Location Insert



(Fig 13) Attach Driver/Left Rear Support Bracket [H] to the pinch weld mounting slots with its lower tab on the rear side of Driver/Left Rear Mounting Bracket [C]




(Fig 14) Attach Driver/Left Rear Support Bracket [H] to Driver/Left Rear Mounting Bracket [C]



(Fig 15) Attach Driver/Left Rear Support Bracket [H] and Driver/Left Rear Mounting Bracket [C]

**STEP 2 MOUNTING RUNNING BOARD**

Follow (Fig 16) to install the running board.



(Fig 16) Attach brackets to drop step (front brackets shown)

## STEP 3 PASSENGER SIDE

Repeat **STEPS 1-2** for passenger side installation.


Use Front Mounting Bracket **[D]** instead of **[A]**;

Use Center Mounting Bracket **[E]** instead of **[B]**;

Use Rear Mounting Bracket **[F]** instead of **[C]**;

Use Front Support Bracket **[J]** instead of **[G]**;

Use Center/Rear Support Brackets **[K]** instead of **[H]**.



## STEP 4

Installation is complete. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

