




TYGER[®]

Part#: TG-RS2T40158

RISER[®]

Parts List

- | | | |
|--|---|-------------------|
| x1 Driver/left Side Step | x1 Passenger/Right Front Mounting Bracket | x12 Plastic Clips |
| x1 Passenger/right Side Step | x12 8-1.25mm x 25mm Combination Bolts | x6 Plastic Covers |
| x2 Driver/Left Center & Rear Mounting Brackets | x12 8mm x 24mm OD x 2mm Flat Washers | |
| x2 Passenger/Right Center & Rear Mounting Brackets | x12 8-1.25mm x 30mm Hex Bolts | |
| x1 Driver/Left Front Mounting Bracket | x12 8mm Lock Washers | |





TYGER[®]

Before Installation

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY. USE ILLUSTRATION TO PROPERLY IDENTIFY BRACKETS AND SIDEBARS.


STEP 1

Starting on the passenger side front of the vehicle, remove the plastic plugs or bolts covering the threaded holes in the body panel, (Figure 1). Select the passenger side front Mounting Bracket, (Figures 2 & 3). Attach the Bracket to the vehicle using the included (2) 8mm x 30mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm Flat Washers, (Figure 2). Do not tighten hardware at this time.

STEP 2


Select (1) Plastic Bracket Cover and (2) Retaining Clips, (Figure 3). Slide the Cover over the front Bracket. Line up the mounting holes in the Cover with the holes in the Bracket. Insert (1) Clip into each hole and push center pin to expand Clip, (Figure 4). Repeat this Step for all Cover installations.

Remove plastic plugs or
factory hex bolts (if equipped)




(Fig 1) Passenger side front mounting location

(2) 8mm x 30mm Hex Bolts
(2) 8mm Flat Washers
(2) 8mm Lock Washers




(Fig 2) Passenger side front Bracket installation

(2) Plastic Clips
for cover



(Fig 3) Passenger front Bracket cover installation



(Fig 4) Push center pin in to expand Clip in Bracket



TYGER[®]

STEP 3

Repeat Steps 1 & 2 for Center and rear Mounting Bracket installation, (Figures 5 & 6).

STEP 4




Select the passenger/right Side Step. Carefully position the Side Step onto the (3) Mounting Brackets. **IMPORTANT:** Do not slide the Side Step on the Brackets or damage to the finish may result. Attach the Side Step to the Mounting Brackets with (6) 8mm x 25mm Combination Hex Bolts, (Figures 7 & 8). Do not tighten hardware.

STEP 5

Level and adjust the Side Step and fully tighten all hardware.

STEP 6


Repeat Steps 1-5 for driver Side Step installation.





STEP 7

Do periodic inspections to the installation to make sure that all hardware is secure and tight.




Torque Value

Fastener Size	Class 8.8 Tightening Torque (ft-lbs)	Class 10.9 Tightening Torque (ft-lbs)
6mm	6-7	6-7
8mm	15-16	22-23
10mm	31-32	44-45
12mm	54-55	78-79
14mm	87-88	125-126

NOTE:

Mild soap may be used to clean the side step



Complete Installation